



Part No.	Dimensions, mm				
	L	W	T	A	ØD
PL 7.65 12 1.5	7.65	12	1.5	2	4
PL 9 12 1.5	9	12	1.5	2	4
PL 15 12 1.5	15	12	1.5	2	4
PL 20 12 1.5	20	12	1.5	2	4

Part No.	Dimensions, mm					
	L	W	T	A	ØD	C
PL 25 12 1.5	25	12	1.5	2	4	14
PL 30 12 1.5	30	12	1.5	2	4	14
PL 40 12 1.5	40	12	1.5	2	4	26
PL 50 12 1.5	50	12	1.5	2	4	26
PL 60 12 1.5	60	12	1.5	2	4	26
PL 80 12 2.2	80	13	2.2	2	4	26
PL 100 12 2.2	100	13	2.2	2	4	26

Part No.	Dimensions, mm				
	L	W	T	A	ØD
PL 12 12 1.5	12	12	1.5	4	4

Part No.	Dimensions, mm				
	L	W	T	A	ØD
PL 14 14 1.5	14	14	1.2	4	8.5
PL 14 14 2	14	14	2	4	6.5

Part No.	Dimensions, mm				
	L	W	T	A	ØD
PL 19.5 12 1.5 EC	19.5	12	1.5	4	4

Part No.	Dimensions, mm					
	L	W	T	A	ØD	C
PL 29.5 9 1.5 EC	29.5	9	1.5	4	4	14
PL 29.5 12 1.5 EC	29.5	12	1.5	4	4	14
PL 39.5 9 1.5 EC	39.5	9	1.5	4	4	26
PL 39.5 12 1.5 EC	39.5	12	1.5	4	4	26
PL 49.5 12 1.5 EC	49.5	12	1.5	4	4	26
PL 59.5 12 1.5 EC	59.5	12	1.5	4	4	26

Part No.	Dimensions, mm					
	L	W	T	A	ØD	C
PL 50 12 1.7 EC	50	12	1.7	4	4	37

Part No.	Dimensions, mm				
	L	W	T	A	ØD
PLR 20 12	20	12	1.5	2	4

Part No.	Dimensions, mm				
	L	W	T	A	ØD
PLT 22	n/a	22	2	3	6.5

Part No.	Dimensions, mm				
	L	W	T	A	ØD
PLS 18	18	18	1.95	4	10.3

EC = End Cut A = Number of cutting edges

REPLACEABLE INSERTS & PARTS FOR REPLACEMENT INSERT ROUTER BITS

REPLACEMENT PARTS		
DESCRIPTION		Part No.
Torx Key	All bits prefix RSP	T14
Torx Key	All other bits	T15
Torx Head Screw	All bits prefix R & RV	M4
Torx Head Screw	All bits prefix RS	M3.5
Torx Head Screw	All bits prefix RSP	M3
Bearing Screw	All bits	M4
Replacement Bearing	All bits prefix R	TB5
Replacement Bearing	All bits prefix RV	TB 4 or TB 20 or TB 18

- NOTE**
- All straight Router Bits without bearings or with a bearing on the shank, are supplied with end cutting inserts.
 - Inserts can be removed and replaced without removing cutter from the routing machine.
- CAUTION**
- DO NOT OVERTIGHTEN TORX SCREWS
 - When tightening screws, ensure that inserts are held firmly into pocket for correct location
 - Ensure tip seating is free of burrs and resin when changing blades.



When ordering replacement blades:
State • Insert Number eg. PL 30 12 1.5

